

Tactical Rovers
Discovery 1 & 2
Rock Slider Install

1. Remove plastic rocker covers and flaps (if so equipped).
2. Using a floor jack, place the slider on the jack and jack up into place with doors open.
3. Close doors and visually center the slider. There may be a slight underhang on the ends to accommodate fender-trimming if larger tires are installed.
4. Once the position looks good, check that there is a small gap along the doorline at the top edge of the slider. This should be between $\frac{1}{4}$ " to $\frac{1}{2}$ ", varying from one vehicle to another.
5. With the jack holding the slider in place, open the doors and drill the $\frac{1}{2}$ " holes for the mounting bolts, using the slider holes as a guide. Repeat on the back side.
 - a. Tip: The back holes are easily done with an angle drill or a short $\frac{1}{2}$ " bit.
6. Install the 3 supplied bolts, tighten snugly and remove jack. Repeat for opposite side.

...Enjoy!

Questions or comments?
Contact the Tactical Rovers Install Team:
eric@tacticalrovers.com
(951) 239-6236